

Safe unloading



Safety regulations in the intake area

Ensure that you are familiar with these regulations!
Follow the rules set out below for your and our safety.

General rules

- In the intake area, always comply with any instructions from the AEB employee.
- Only sound your horn in case of danger.
- You must stop your vehicle before the line by the stop sign at the entrance to the intake area. You may proceed when the light turns green.
- Dutch traffic regulations apply (Road Traffic Act 1994, *wegenverkeerswet*).
- You must be 18 years or over to enter the intake area.
- Smoking is prohibited, including in the cabin of your vehicle.
- Only step in and out of your vehicle when it is stationary, and never jump.
- It is not permitted to hose down or sweep out any vehicle in the intake area.



Vehicles and containers

- Broken down or poorly maintained vehicles and containers will not be admitted.
- Containers should not be loaded any fuller than a maximum of 20 cm below the rim.
- Containers should not be loaded over the legally prescribed tonnage limit.
- Containers should be fitted with a secure bolt.
- Do not drive with or unload unsecured containers.

Removing container covers

- Do not remove tarpaulins or covers from containers prior to unloading waste.
- Covers should only be removed in the cover removal zone.
- Park your vehicle directly alongside the cover removal zone. Fold nets and tarpaulins away tidily between the vehicle and the wall.
- Only remove other cover systems when you have received permission from the AEB employee and only in the cover removal zone.

Waste unloading procedure

- The co-driver should remain in the vehicle while the driver performs the unloading tasks.
- Reverse up to the line (3 meters) before the waste pit.
- Unbolt the container door and ensure it is properly secured, then open the barrier.
- Reverse slowly to the edge of the pit and unload the waste.
- Remain behind the barrier yourself until all the waste has been unloaded.
- When the container is empty, close the barrier again.
- Sweep any spilled waste into the pit with a broom.

Please note:

- Do not walk or stand beneath raised hydraulic lifting systems.
- Do not climb into the container or onto the vehicle unless authorised to do so by the AEB employee.
- Do not unload any waste onto the unloading floor.



Personal protective equipment (PPE)

- The following PPE is required: clear safety goggles, safety footwear, high-visibility vest or jacket and fully closed clothing covering the whole body.
- Drivers of container trucks not fitted with side bolts are required to wear a helmet.



Container exchange area

- PPE must be worn in the container exchange area.